

# PC920 Power OPIC Photocoupler

T-41-83

## ■ Features


1. High power  
( $I_{o1}$  : MAX. -0.8A (DC))  
( $I_{o2}$  : MAX. 1.6A (Pulse))
2. Low input current drive  
( $I_{FLH}$  : MAX. 2mA at  $T_a = T_{opr}$ )
3. Operating supply voltage  $V_{cc}$  : 5.4~15V
4. Compact single-in-line package (With heat sink)
5. UL recognized, file No. E64380

## ■ Applications

1. Inverter controlled air conditioners

## ■ Outline Dimensions

(Unit : mm)



\* OPIC is a registered trademark of Sharp and stands for Optical IC. It has a light detecting element and signal processing circuitry integrated onto a single chip.

## ■ Absolute Maximum Ratings

 $(T_a = 25^\circ C)$ 

Parameter	Symbol	Rating	Unit
Input	$I_F$	50	mA
	$V_R$	6	V
	P	70	mW
Output	$V_{cc}$	16	V
	$I_{o1}$ output current	-0.8	A
	* $I_{o2}$ output current	1.6	A
Total power dissipation	$P_{tot}$	1,200	mW
* $V_{iso}$ Isolation voltage	$V_{iso}$	1,500	Vrms
Operating temperature	$T_{opr}$	-20 ~ +80	°C
Storage temperature	$T_{stg}$	-55 ~ +125	°C
* $T_{sol}$ Soldering temperature	$T_{sol}$	260	°C

\*1 Pulse width  $\leq 10\mu s$ , Duty ratio = 0.02

\*2 RH = 40 ~ 60%, AC for 1 minute

\*3 For 10 seconds

(Ta=25°C unless specified)



## ■ Electro-optical Characteristics



Parameter		Symbol	Conditions	MIN.	TYP.	MAX.	Unit
Input	Forward voltage	V <sub>F</sub>	I <sub>F</sub> =2mA	—	1.1	1.4	V
			I <sub>F</sub> =0.1mA	0.6	0.95	—	
	Reverse current	I <sub>R</sub>	V <sub>R</sub> =3V	—	—	10	μA
Output	Terminal capacitance	C <sub>t</sub>	V=0, f=1kHz	—	30	80	pF
	Operating supply voltage	V <sub>CC</sub>		5.4	6.0	15	V
	V <sub>O1</sub> output voltage	V <sub>O1</sub>	V <sub>CC</sub> =V <sub>CC1</sub> =6V, I <sub>O1</sub> =-0.3A, I <sub>F</sub> =2mA	4.5	5.2	—	V
	V <sub>O2</sub> output voltage	V <sub>O2</sub>	V <sub>CC</sub> =V <sub>CC1</sub> =6V, I <sub>O2P</sub> =1A, I <sub>F</sub> =0	—	0.3	2.0	V
	V <sub>O1</sub> leak current	I <sub>OL1</sub>	V <sub>CC</sub> =V <sub>CC1</sub> =6V, V <sub>O1</sub> =GND, I <sub>F</sub> =0	—	—	200	μA
	V <sub>O2</sub> leak current	I <sub>OL2</sub>	V <sub>CC</sub> =V <sub>CC1</sub> =V <sub>O2</sub> =6V, I <sub>F</sub> =2mA	—	—	200	μA
	High level supply current	I <sub>CCH</sub>	V <sub>CC</sub> =V <sub>CC1</sub> =6V, I <sub>F</sub> =2mA	—	5	10	mA
Transfer characteristics	Low level supply current	I <sub>CCL</sub>	V <sub>CC</sub> =V <sub>CC1</sub> =6V, I <sub>F</sub> =0	—	12	20	mA
	**"Low→High" threshold input current	I <sub>PLH</sub>	V <sub>CC</sub> =V <sub>CC1</sub> =6V, R <sub>L1</sub> =15Ω	—	0.5	1.0	mA
			Ta=T <sub>opt</sub> , V <sub>CC</sub> =V <sub>CC1</sub> =6V, R <sub>L1</sub> =15Ω	0.1	—	2.0	mA
	Isolation resistance	R <sub>ISO</sub>	DC=500V, RH=40~60%	5×10 <sup>10</sup>	10 <sup>11</sup>	—	Ω
	"Low→High" propagation time	t <sub>PLH</sub>	V <sub>CC</sub> =V <sub>CC1</sub> =6V	—	3	10	μs
	"High→Low" propagation time	t <sub>PHL</sub>	I <sub>F</sub> =2mA	—	3	10	
Response time	Rise time	t <sub>r</sub>	R <sub>L1</sub> =15Ω	—	0.2	2	
	Fall time	t <sub>f</sub>	R <sub>L2</sub> =18Ω	—	0.2	2	

\*4 I<sub>PLH</sub> represents forward current when output goes from "low" to "high".


## ■ Truth Table

Input	Output	T <sub>r1</sub>	T <sub>r2</sub>
ON	High level	ON	OFF
OFF	Low level	OFF	ON

Test Circuit for V<sub>O1</sub>Test Circuit for V<sub>O2</sub>

Test Circuit for  $I_{OL1}$ Test Circuit for  $I_{OL2}$ 

Test Circuit for Response Time



6

Fig. 1 Forward Current vs. Ambient Temperature















Fig. 2 Total Power Dissipation vs. Ambient Temperature



T-41-83

**Fig. 3 Forward Current vs. Forward Voltage****Fig. 4 Relative Threshold Input Current vs. Supply Voltage****Fig. 5 Relative Threshold Input Current vs. Ambient Temperature****Fig. 6 Output Voltage vs. Output Current ( $\text{Tr}_1$ )****Fig. 7 Output Voltage vs. Output Current ( $\text{Tr}_2$ )****Fig. 8 Output Voltage vs. Ambient Temperature ( $\text{Tr}_1$ )**

T-41-83

**Fig. 9 Output Voltage vs. Ambient Temperature ( $T_{r_2}$ )****Fig. 10 Supply Current vs. Supply Voltage****Fig. 11 Propagation Time vs. Forward Current****Fig. 12 Propagation Time vs. Ambient Temperature**

6

**■ Application Circuit Example**